## INSTALLING ACTIVE DIRECTORY DOMAIN SERVICES (WINDOWSSERVER 2008R2)

- 1. Click start
- 2. Right click computer
- 3. Click manage or search server manager in the search box
- 4. Click Roles
- 5. Click add roles
- 6. Next
- 7. Check the Active Directory Domain

#### DCPROMO INSTALLATION ( PC server first then PC client )

- 1. Click start
- 2. Search "cmd" on the search box or windows button + R then search "cmd"
- 3. Click OK or enter
- 4. Type "Dcpromo"
- 5. Check use advanced mode installation
- 6. Next
- 7. Next > Check Automatic correct the problem by installing DNS
- Click create a new domain in a new forest
- 9. Next
- Write your YOURNAME.com ( Example: CDM.com )
- 11. Next
- 12. Next
- 13. Choose Windows 2003

#### Services (ADDS)

- 8. Click add features requirements ( if there is )
- 9. Next
- 10. Next
- 11. Click Install
- 12. Wait until it finished
- 13. Click close
- 14. Restart
- 14. Next
- 15. Next
- Click DNS server ( if there is a check already, just leave it )
- 17. Click Yes
- 18. Next
- Write your password (Example: Css@2021)
- 20. Next
- 21. Next
- 22. Check reboot on completion
- 23. Wait until finished
- 24. Go to PC client
- 25. Click start
- 26. Right click computer
- 27. Click properties



- 28. Click change settings
- 29. Click Change
- 30. Click domain
- 31. Input the created Domain example: CDM
- 32. Ok

- Input Username and Password of the PC server (Administrator, Css@2021)
- 34. Wait until finished
- 35. <u>PUT DNS SERVER ADDRESS FROM YOUR</u> <u>SERVER</u>
- 36. Restart PC client

#### TROUBLESHOOTING TECHNIQUES

CLIENT CANNOT JOIN TO THE DOMAIN

- Check LAN card driver of both PC make sure that it is installed
- Check IP address. Make sure it is in the same subnet (Example: 192.168.1.1 and 192.168.1.2)
- Change IP address
- On the Add Roles, check DCPROMO status and try to restart it
- Restart your system
- Check Both Computer Name (It must be Different Computer Name)
- Re-install DCPROMO
- Install Fresh Server 2008 R2

#### FILE SERVICES INSTALLATION ( PC SERVER ONLY )

- 1. Click start
- 2. Right click computer
- 3. Click manage
- 4. Click roles
- 5. Click add roles
- 6. Next
- 7. Check file services
- 8. Next

- Check file server resources manager and windows search service
- 10. Next
- 11. Next
- 12. Click Install
- 13. Wait until finished
- 14. Click close
- 15. Restart



#### FOLDER REDIRECTION CONFIGURATION ( PC server first then PC client )

- 1. Go to Drive d:
- 2. Create new folder rename it to ICT 2<sup>nd</sup>
- 3. Right click, share with
- 4. Everyone make it read/write, Click Share

Take Note the network path of the shared folder, Example \\SERVER-WIN2008\Redirection

- 5. Click Done
- 6. Click Server Manager
- 7. Click (+) Roles
- 8. Click (+) Active Directory Domain Services
- Click (+) Active Directory Users and Computers
- 10. Click (+) Domain you created
- 11. Right click the domain you created
- 12. Click new>Click Organizational Unit
- Write name of organizational unit (Example: Your name)
- 14. Check the protect container from an accidental deletion
- 15. Click OK
- Right click your created Organizational Unit
- 17. Click new>User
- 18. Fill up the form FirstName,LastName,FullName ,UserLogon Name
- 19. Click Next

- 20. Uncheck user must change password at next log on
- 21. Check the user cannot change password and password never expire
- 22. Input your password Ex, Kvshs2018
- 23. Click Next
- 24. Click finish
- 25. Go to Client-Win7then Login your created users
- 26. Click start
- 27. Click expansion on the shutdown
- 28. Click switch users
- 29. Click Log in other user
- 30. Input the created user account Example: juancruz
- 31. Back to PC server
- 32. Click start
- 33. Click administrative tools
- 34. Click Group Policy Management
- 35. Click (+) Forest: Domain name
- 36. Click (+) Domains
- 37. Click (+) Domain Name you created
- 38. Right click the Organizational Unit
- 39. Click Create GPO in this domain
- 40. Input GPO name >ok
- 41. Select the GPO then right Click Edit



- 42. On right side of your screen Double click
  User Configuration
- 43. Double Click Policies
- 44. Double Click Windows settings
- 45. Double Click Folder Redirection
- 46. Right click Desktop
- 47. Click Properties
- 48. Click Dropdown menu>Select Basic-Redirect everyone's folder to the same location
- 49. Paste the root path of the folder created in drive D: example: \\SERVER-\WIN2008\Redirection
- 50. Click Settings Tab
- 51. Check also apply redirection policy and check redirect the folder back to the local
- 52. Click apply
- 53. Click OK
- 54. Apply the same configuration in

#### TROUBLESHOOTING TECHNIQUES

- 1. Folder redirection cannot locate
  - Double Check the address path
- 2. Failed to Redirect Folder
  - Delete all the existing redirection folder then create new folder redirection and then try again
  - Format the drive before create new folder redirection

Documents folder

- 55. Back to the created GPO
- 56. Right click Enforced
- 57. Click OK
- 58. Click start
- 59. Go to "cmd"
- 60. Type "gpupdate/force"
- 61. Type "y" if there is a choice of "y/n" pop out on the cmd if there is no such thing then proceed
- 62. Restart PC

# CHECKING THE FOLDER REDIRECTION (PC SERVER AND PC CLIENT)

- 1. Go to PC client
- Create folder on desktop and documents
- 3. Go to PC server
- 4. Check the created folder in drive D:



#### DHCP INSTALLATION ( PC SERVER ONLY )

Note: Before you install DHCP make sure you remove the internet connection from the ISP

- 1. Click start
- 2. Right click computer
- 3. Click manage
- 4. Click add roles
- 5. Next
- 6. Check DHCP server
- 7. Next
- 8. Next
- 9. Next
- 10. Next
- 11. Next
- 12. Click add
- 13. Fill up the add scope
- 14. Put the scope name (Example: YOUR NAME)
- 15. Put the starting IP address (Example: 192.168.9.22)
- 16. Put the starting IP address (Example: 192.168.9.100)
- 17. Click OK
- 18. Next

#### **CONFIGURING ACCESS POINT**

- 1. Power on the Access point
- 2. Use solid wire to reset the Access Point
- 3. Connect the one end of CAT5 cable to

- 19. Click Disable DHCPv6
- 20. Next
- 21. Next
- 22. Click Install
- 23. Wait until finished
- 24. Restart PC

#### CHECKING THE SCOPE ( PC CLIENT ONLY )

- 1. Click start
- 2. Click control panel
- 3. Click network and Internet
- 4. Click network and Sharing
- 5. Click adapter setting
- 6. Right click Local Area Connection
- 7. Click properties
- 8. Double click IPv4
- 9. Obtain IP address
- 10. Go to command prompt (cmd)
- 11. Type "ipconfig/all"
- 12. Look at the IPv4 preferred IP address if it is within the scrope range of starting IP address and the ending of IP address
  - the PC and other end to the access point
- 4. Configure The IP Address Change it to Obtain an IP Automatically



- 5. Open any Web Browser
- On the address bar type the existing Url of the Access Point http:// dlinkapor 192.160.0.50 you can locate this under the access point
- New page will pop-up (Make sure it contain the login page for the Access Point)
- 8. User Name: Admin Password: There is no configure Password yet Just click Log -in
- 9. On the wireless connection setup wizard page
- 10. Click Launch Wireless Setup Wizard
- 11. Click Next
- 12. On Wireless mode Choose Access Point
- 13. Click Next
- 14. Input your WiFi new Network Name

#### And Network password

- 15. Click Next
- 16. Click Save
- 17. After configuring the Access Point remove the Access Point from the PC
- 18. The connect it to the patched ISP port
- 19. Then connect your phone for checking
- 20. Open Any Website in your Cellphone

### HOW TO CREATE REMOTE ACCESS SERVER

- 1. Click Start
- 2. Control Panel
- 3. System and Security
- 4. System
- 5. Advance System settings
- 6. Go to Remote Tab
- 7. Click Allow connections
- 8. Click Ok
- 9. Click Apply

#### 10. Finish

### Checking:

- Click start On Search box type Remote Desktop
- Click remote Desktop Connection (RDC)
- Click Options to view full details
- Enter the computer name of the remote computer

#### **CLIENT**

- 1. Click Start
- 2. Control Panel
- 3. System and Security
- 4. System
- 5. Advance System settings
- 6. Input User account
- 7. Input Admin Password
- 8. Go to Remote Tab
- 9. Check Allow Connection from computers
- 10. Click Apply
- 11. Click Ok

